




# 03a - V6 Bowden Tool Assembly.

Written By: Dan Rock



## Step 1 — Gather Parts.



- Gather:
- x1 V6 Receiver Top
- x1 V6 PCF Duct
- x1 V6 PCF Fan Bracket
- x1 V6 Cable Support
- Please note these parts are not included, you will need to print these yourself.
- Download the files from [GitHub](#).

## Step 2 — Prepare parts.





- Tap M2.5 Threads into the three holes in the printed PCF Fan Bracket.
- Tap an M3 thread into the printed Top.

## Step 3 — Gather Parts.




- Gather:
- x1 TC Receiver.
- x1 V6 fixings kit.
- x1 tool plate.

## Step 4 — M6



- Apply a drop of super glue to the M6 grub screw.

## Step 5




- Using a flat surface (not necessarily a tool plate) make sure the end of the M6 grub screw is flush with the surface of the plastic part.

## Step 6



- Apply thread lock to the counter sunk M3x8 Screw.
- Screw the Tool plate onto the TC receiver.

## Step 7




- Fasten the second counter sunk M3x8 screw.
- Also use thread lock for this screw.

## Step 8 — Gather Parts.




- Gather:
- x1 V6 PCF Fan Bracket
- x2 Socket Cap Head M3x6 screws.
- x1 TC- HE- V6

## Step 9



- Apply thread lock to the end of the M3x8 socket cap screw.
- Screw the bracket onto the aluminium part.

## Step 10




- Fasten the second M3x8 socket cap screw

## Step 11 — Gather Parts.



- Gather:
- x1 braket assembly. (what you just assembled.)
- x1 V6 threaded heatsink.
- x1 M12 nut.

## Step 12




- Place the threaded heat sink through the aluminium
- Screw on the M12 plastic nut.

## Step 13 — Gather Parts.




- Gather:
- x1 0.4mm 1.75 brass nozzle.
- x1 Thermal compound.
- x1 1.75mm heat break.
- x1 V6 heater block.
- x1 Collet.
- x1 Collet clip.

## Step 14




- Screw in the heat break.
- Screw in the nozzle.
- Check the nozzle is aligned as shown when the heatbreak is installed.
- Refer to the [V6 Assembly Guide](#) if you are unsure.

## Step 15



- Press in the collet.
- Slide in the collet clip.

## Step 16




- Apply thermal paste to the long section of the heat break.

## Step 17




- Screw in the heater block assembly into the heatsink.

## Step 18




- The assembly should look as follows at this stage.

## Step 19




- Gather Parts.

## Step 20 — Fasten the fan.




- Screw the x4 plasti fast screws into the fan duct.
  - Make sure the sticker will be facing towards the heat sink for correct cooling.
- Compare the orientation of the fan duct to the picture to make sure you press it on the correct way round.

## Step 21




- Press the fan duct onto the heat sink.

## Step 22 — Cable Management



- Slot the fan wires through the slot in the V6 PCF Fan Bracket.

## Step 23




- Slide in the thermistor.
- Fasten the grub screw to hold the thermistor in place.
- Be careful not to over tighten the screw as this will permanently damage the thermistor.

## Step 24




- The thermistor wire will not be able to be passed through the slot at this stage so just leave it loose.

## Step 25 — Check orientation.




- At this stage the assembly should look as follows.

## Step 26 — Gather Parts.




- Gather:
- The tool head assembly.
- Black M3 button head screw
- High precision heater cartridge.

## Step 27 — Fasten heater cartridge.



- Slide in the heater cartridge.
  - Screw in the black M3 screw to fasten the heater cartridge in place.
- (i)* It is expected that the aluminium will deform slightly.

## Step 28 — Cable Management.




- Slot the heater cartridge wire though the slot in the V6 PCF Fan Bracket.

## Step 29 — Check Orientation.




- At this stage the assembly should look like this.

## Step 30 — Gather Parts




- Gather the tool head assembly.
- The tool plate assembly.
- x2 counter sunk M Screw.

## Step 31



- Apply thread lock to the counter sunk screws.
- Fasten the Tool plate to the Tool Head assembly.

## Step 32 — Check Orientation.



- At this stage the assembly should look as follows.

## Step 33 — Gather Parts.




- Gather the Tool head assembly.
- Fan duct.
- Part cooling fan.
- x3 screws.

## Step 34




- Slot the fan duct onto the part cooling fan.

## Step 35 — Cable Management.




- Take the part cooling fan wire and pass it through the slot in the V6 PCF Fan Bracket.

## Step 36




- Place the Fan and Duct onto the tool head assembly as shown.

## Step 37




- Secure the fan with an M3 counter sunk screw.

## Step 38



- Partially screw the grub screw into the top as shown.

## Step 39





- Gather Parts.

## Step 40





- Place the printed bracket on top.
- Secure using the printed top and four screws.

## Step 41



- Tighten the screws.

## Step 42 — Sock.



- Fit the sock.